


Tips for Successful Installation of Blast LED Acrylic Speaker Rings

• Follow the diagram below for easy installation:

LED RING INSTALLATION GUIDE



- LED strip is glued to the acrylic ring using superglue. It may come off during ring installation or due to hot weather. The strip may be adhered back using any superglue.
- Remove the brown paper protectant on the surface of the acrylic ring prior to installing with the speakers. Failure to remove the protectant may result in getting the paper wet at a later time and stick to the surface of the speaker.
- We offer 1-yr replacement warranty on LED strips. If the LEDs on the ring go bad or rings don't light up, please contact us at info@blastled.com for warranty claim.

Email: <u>info@blastled.com</u>
Website: www.blastled.com